使用Yolov5训练kitti数据

- 配置Yolov5环境
- 转换kitti数据集格式
- 使用Yolov5训练数据集

Windows环境下使用Anaconda配置Yolov5环境

1. 创建虚拟环境

conda create -n pytorch python=3.7

第一步创建anaconda虚拟环境,命名pytorch

conda activate pytorch

进入新创建的虚拟环境

2. 安装pytorch



在虚拟环境中运行这个指令

3. 安装Yolov5

github下载并解压到本地后,按照项目文件里的requirement.txt安装所需包。

```
pip install -r requirement.txt
```

转换kitti数据集格式

1.下载kitti数据集

转到官网

http://www.cvlibs.net/download.php?file=data_object_image_2.zip

http://www.cvlibs.net/download.php?file=data_object_label_2.zip

得到图片和标签

在dataset文件夹按如下框架储存数据,其中labels数据需要转换后在存储

```
-kitti
 1
 2
        imgages
 3
            - val
 4
              └─ 000000.png
 5
 6
 7
           — train
 8
                 000000.png
 9
10
        labels
11
         └─ train
12
```

2.labels数据格式转换

首先将类别简化为三类,其中包括car, Pedestrian, Cyclist。

```
import glob
import string
```

```
txt list = glob.glob('你下载的标签文件夹的标签路径/*.txt')
def show category(txt list):
    category list= []
    for item in txt list:
       try:
           with open(item) as tdf:
               for each line in tdf:
                   labeldata = each line.strip().split('') # 去
掉前后多余的字符并把其分开
                   category list.append(labeldata[0]) # 只要第一
个字段, 即类别
       except IOError as ioerr:
           print('File error:'+str(ioerr))
    print(set(category list)) # 输出集合
def merge(line):
    each line=''
    for i in range(len(line)):
       if i!= (len(line)-1):
           each line=each line+line[i]+' '
       else:
           each line=each line+line[i] # 最后一条字段后面不加空格
    each line=each line+'\n'
    return (each line)
print('before modify categories are:\n')
show category(txt list)
for item in txt list:
    new txt=[]
    try:
       with open(item, 'r') as r_tdf:
           for each line in r tdf:
               labeldata = each line.strip().split(' ')
               if labeldata[0] in ['Truck','Van','Tram']: # 合并
汽车类
                   labeldata[0] =
labeldata[0].replace(labeldata[0], 'Car')
               if labeldata[0] == 'Person_sitting': # 合并行人类
                   labeldata[0] =
labeldata[0].replace(labeldata[0], 'Pedestrian')
               if labeldata[0] == 'DontCare': # 忽略Dontcare类
                   continue
               if labeldata[0] == 'Misc': # 忽略Misc类
                   continue
               new_txt.append(merge(labeldata)) # 重新写入新的txt
```

然后再把它转换为xml文件,创建一个Annotations文件夹用于存放xml

```
from xml.dom.minidom import Document
import cv2
import os
def generate xml(name,split lines,img size,class ind):
    doc = Document() # 创建DOM文档对象
    annotation = doc.createElement('annotation')
    doc.appendChild(annotation)
   title = doc.createElement('folder')
    title_text = doc.createTextNode('KITTI')
    title.appendChild(title text)
    annotation.appendChild(title)
    img name=name+'.png'
   title = doc.createElement('filename')
    title text = doc.createTextNode(img name)
   title.appendChild(title text)
    annotation.appendChild(title)
    source = doc.createElement('source')
    annotation.appendChild(source)
    title = doc.createElement('database')
    title text = doc.createTextNode('The KITTI Database')
   title.appendChild(title text)
    source.appendChild(title)
   title = doc.createElement('annotation')
    title text = doc.createTextNode('KITTI')
    title.appendChild(title_text)
    source.appendChild(title)
    size = doc.createElement('size')
    annotation.appendChild(size)
    title = doc.createElement('width')
    title text = doc.createTextNode(str(img size[1]))
    title.appendChild(title_text)
```

```
size.appendChild(title)
    title = doc.createElement('height')
    title text = doc.createTextNode(str(img size[0]))
    title.appendChild(title text)
    size.appendChild(title)
    title = doc.createElement('depth')
    title text = doc.createTextNode(str(img size[2]))
    title.appendChild(title text)
    size.appendChild(title)
    for split line in split lines:
        line=split line.strip().split()
        if line[0] in class ind:
            object = doc.createElement('object')
            annotation.appendChild(object)
            title = doc.createElement('name')
            title text = doc.createTextNode(line[0])
            title.appendChild(title text)
            object.appendChild(title)
            bndbox = doc.createElement('bndbox')
            object.appendChild(bndbox)
            title = doc.createElement('xmin')
            title text =
doc.createTextNode(str(int(float(line[4]))))
            title.appendChild(title text)
            bndbox.appendChild(title)
            title = doc.createElement('ymin')
            title text =
doc.createTextNode(str(int(float(line[5]))))
            title.appendChild(title text)
            bndbox.appendChild(title)
            title = doc.createElement('xmax')
            title text =
doc.createTextNode(str(int(float(line[6]))))
            title.appendChild(title text)
            bndbox.appendChild(title)
            title = doc.createElement('ymax')
            title text =
doc.createTextNode(str(int(float(line[7]))))
            title.appendChild(title text)
            bndbox.appendChild(title)
    #将DOM对象doc写入文件
    f = open('Annotations/trian'+name+'.xml','w')
    f.write(doc.toprettyxml(indent = ''))
```

```
f.close()
if name == ' main ':
   class ind=('Pedestrian', 'Car', 'Cyclist')
   cur dir=os.getcwd()
   labels dir=os.path.join(cur dir, 'Labels')
   for parent, dirnames, filenames in os.walk(labels dir): # 分别
得到根目录, 子目录和根目录下文件
       for file name in filenames:
           full path=os.path.join(parent, file name) # 获取文件全
路径
           f=open(full path)
           split lines = f.readlines()
           name= file_name[:-4] # 后四位是扩展名.txt, 只取前面的文
件名
           img name=name+'.png'
           img path=os.path.join('./JPEGImages/trian',img name) #
路径需要自行修改
           img size=cv2.imread(img path).shape
           generate_xml(name,split_lines,img_size,class_ind)
print('all txts has converted into xmls')
```

最后再把.xml转化为适合于yolo训练的标签模式,也就是darknet的txt格式

```
import glob
import xml.etree.ElementTree as ET
# 这里的类名为我们xml里面的类名,顺序现在不需要考虑
class names = ['Car', 'Cyclist', 'Pedestrian']
# xml文件路径
path = './Annotations/'
# 转换一个xml文件为txt
def single xml to txt(xml file):
   tree = ET.parse(xml file)
   root = tree.getroot()
   # 保存的txt文件路径
   txt file = xml file.split('.')[0]+'.'+xml file.split('.')
[1]+'.txt'
   with open(txt file, 'w') as txt file:
       for member in root.findall('object'):
           #filename = root.find('filename').text
           picture width = int(root.find('size')[0].text)
           picture height = int(root.find('size')[1].text)
           class name = member[0].text
           # 类名对应的index
```

```
class num = class names.index(class name)
           box x min = int(member[1][0].text) # 左上角横坐标
           box y min = int(member[1][1].text) # 左上角纵坐标
           box x max = int(member[1][2].text) # 右下角横坐标
           box y max = int(member[1][3].text) # 右下角纵坐标
           print(box x max,box x min,box y max,box y min)
           # 转成相对位置和宽高
           x center = float(box x min + box x max) / (2 *
picture width)
           y center = float(box y min + box y max) / (2 *
picture height)
           width = float(box_x_max - box_x_min) / picture_width
           height = float(box y max - box y min) /
picture height
           print(class_num, x_center, y_center, width, height)
           txt file.write(str(class num) + ' ' + str(x center) +
' ' + str(y_center) + ' ' + str(width) + ' ' + str(height) + '\n')
# 转换文件夹下的所有xml文件为txt
def dir xml to txt(path):
   for xml_file in glob.glob(path + '*.xml'):
       single_xml_to_txt(xml_file)
dir_xml_to_txt(path)
```

最后将得到的Annotations/下的所有txt文件放入之前的dataset/labels中

使用yolov5训练模型

首先在data文件夹中复制一份coco.yaml然后改名kitti.yaml修改内容

```
train: D:\yolov5master\data\kitti\images # train images (relative
to 'path') 118287 images
val: D:\yolov5master\data\kitti\images # train images (relative
to 'path') 5000 images

# Classes
nc: 3 # number of classes
names: ['Car','Pedestrian','Cyclist'] # class names
```


在models文件夹修改yolov5s.yaml内容

nc: 3 # number of classes

开始训练

python train.py --img 640 --batch-size 16 --epochs 10
--data data/kitti.yaml --cfg models/yolov5s.yaml
--weights yolov5s.pt

在runs/train/exp下可以看到训练的结果



拿着训练完的最好的权重尝试结果

python detect.py --weights runs/train/exp6/weights/best.pt
--source data/kitti/images/val/000000.png --device 0

